


AMPLIROLL® HOOKLIFTS
EQUIPMENT CONFIGURATION
HYDRAULIC LINES - FROM FACTORY



1 **HYDRAULIC LINES - FROM FACTORY**
CRANE SUPPLY

HYDRAULIC LINE - REAR CAB MOUNTED CRANE
MANUAL



The hydraulic line is manually selected by the operator (Crane or Ampliroll®).
Can be fitted with a side or vertical box.


HYDRAULIC LINE - REAR CAB MOUNTED CRANE
(PNEUMATIC)
SINGLE OR DOUBLE CIRCUIT



*Double circuit
configuration*

The operator selects the circuit to be used (Crane or Ampliroll®) on the
associated control panel in the cab (depending on the Ampli'Drive Pack).
Can be fitted with a side or vertical box.

HYDRAULIC LINE FOR CRANE ON SKIP
SINGLE CIRCUIT



The operator selects the circuit to be used (Crane or Ampliroll®) on the
associated control panel in the cab (depending on the Ampli'Drive Pack).
Can be fitted with a side or vertical box.

*Assembly with side
control box*

