

## AMPLIROLL® HIGH OPTIONS

### SEQUENCE MODE EVERYDAY PRODUCTIVITY & CONVENIENCE

Ease of use thanks to the automation of movements for picking up and setting down containers (increased productivity).

Function available on the **ELECTRIC FIT DRIVE** control.

#### One single button on the control


Location according to configuration



AMPLI'DRIVE


START OPTI PRO

> OPTI  
VAL05607  
> PRO  
VAL05504



Active Sequence Mode

Then use the "Arm" control lever until the sequence stops.



## KEY POINTS

### PERFORMANCE

Save time by automating a sequence of several movements

### COMFORT

One button to activate the option

### Containers Pick-up Movement

⚠ Check that the RUP is retracted and that the rear lock is not closed before starting the sequence.



- 1- Retraction of the telescopic jib
- 2- Extension of the arm
- 3- Extension of the telescopic jib (stopped by the operator)
- 4- Locking of the container

RUP extension has to be operated manually.

### Containers Set down Movement



- 1- When RUP: retraction of the RUP
- 2- Opening of the hydraulic rear lock
- 3- Retraction of the telescopic jib
- 4- Deployment of the arm toward the rear

(Option: smart adjustment of hook height for automatic stop before cycle resumption)